

e-Terra Browser WebFG Viewer Configuration Guide

April 20, 2010

Southwest Power Pool

Revision	Date	Modified By	Update History
Rev. 1.0	4/20/2010	Todd Chumley	Document creation for 2010 Non-Critical System Transition Project

Introduction 2
1. Getting Started 3
a. Downloading configuration file 3
2. Making your change 3
a. Copying file to target location 3
3. Login for RDServer 4
a. e-terrabrowser Login for RDServer 4

Introduction

This document provides a detailed process to guide you through the steps of configuring the WebFG Viewer for the new RDServer.

1. Getting Started

a. Downloading configuration file

i. Navigate to http://dcpwebfgc/habweb_rds_prod/Webfg_install/

ii. Right mouse click on ***New_RDServer_Config.txt*** and select "Save Target as…" – ***This step will take approximately 1 minute based on your internet speed***



iii. Save in desired location

2. Making your change

a. Copying file to target location

i. Copy ***New_RDServer_Config.txt*** to ***%WEBFGROOT%***.
Typically your install path reads as follows:
C:\Program Files\AREVA\e_terrabrowser\WebFGCache\Config



ii. Modify your shortcut, ***RDServer_fgdcp_webfgc_15,*** to reflect the new configuration file (***New_RDServer_Config.txt***).



3. Login for RDServer

a. e-terrabrowser Login for RDServer

i. Execute the ***RDServer_fgdcp_webfgc_15*** shortcut by double clicking on it.

ii. Enter your login information
   1. *USERID:* *your_information*
   2. *PASSWORD:* *your_information*

iii. Click the button **BUS SUM** and make sure that you are looking at the Bus Summary for **BRAPID CLEC**

iv. ***Once your connection is verified…please email tchumley@spp.org confirming your success***